



LED PLL Direct to Mains 12059

Installation Instructions



THANK YOU for buying this Crompton Lamps LED product.

To help ensure this LED PLL gives complete satisfaction - only use it according to the following instructions, and then pass the instructions to the appropriate person for retention and future reference.

WARNING

When installing or using this LED PLL, basic safety precautions should always be followed, including the following:

1. Read all instructions
2. Switch off the power supply before installation or maintenance
3. The LED PLL is designed for indoor use and dry place application.
For any other application, please use in conjunction with a fixture meeting the appropriate IP requirements
4. This LED PLL is not suitable for dimming
5. This LED PLL is not suitable for emergency circuits
6. Do not exceed the nominal supply voltage or amperage ratings
7. Do not operate if product is damaged
8. Apply warning label to fitting after ballast is bypassed




WARNING:

For use only with Crompton Lamps
LED PLL DIRECT TO MAINS
This luminaire has been modified and will no longer operate a fluorescent lamp
See www.cromptonlamps.com for details

NEW Installation / Ballast Bypass

Only to be carried out by a qualified electrician

- 1 Switch off the power
- 2 Remove the fluorescent PLL
- 3 Rewire the circuit as per guidelines
(Note: The pins are not polarity sensitive)
- 4 Insert the LED PLL Tube
- 5 Stick warning label onto luminaire



Environmental Protection

Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist.

Check with your Local Authority or retailer for recycling advice.

Lighting brilliance since 1878

Tel: +44 (0)1274 657 088 **Fax:** +44 (0)1274 657 087

Email: lamps@cromptonlamps.com **Web:** www.cromptonlamps.com